

**COMFAST**


**Outdoor AP**

**Quick installation Guide**




Outdoor AP  
Version 1.0

## 1. Device connection diagram




2. The device is factory-set to router mode by default. To access the settings page:

- (1) In the default configuration, power on the device and wait approximately 90 seconds for it to boot up;
- (2) Connect to the device's wireless SSID (default: COMFAST-XXXX-2G/COMFAST-XXXX-2G, where XXXX represents the last four digits of the device's MAC address);
- (3) Open your computer's web browser, enter 192.168.10.1 to access the device management page (default password: admin). The device supports both Chinese and English languages. You can change the language settings via the icon in the top-right corner.



3. Enter the device wizard page. The "Configuration Wizard" page has four working modes: AP mode, bridge mode, routing mode (broadband Internet access, static address, dynamic acquisition), and relay mode.



4. Click AP Mode. For easier management, the IP address entered here should be within the IP subnet of the upstream router, and the IP address must not conflict with the IP address of the upstream router. After configuration, the LAN port of the POE power supply connected to the external network can access the management device via the configured IP address.

① Note: When accessing the external network in AP mode, the IP address subnet obtained by other mobile devices connecting to the AP's wireless network is assigned by the upper-level device.

② The AP itself requires an internal network IP address (do not set the same IP address as the upper-level router gateway). If you need to manage the device, the PC connected to this AP must manually set an IP address in the same subnet as the internal network IP address.

① Lan Settings ② Wireless ③ Finish

Lan Settings

IP Address: 192.168.10.1

Subnet Mask: 255.255.255.0

Next

5. AP Mode: You can set the 2.4G/5.8G wireless SSID name and password, as well as advanced wireless parameters such as channel bandwidth, country, and channel. After configuration, connect the LAN port of the POE power supply to the external network; other mobile devices can connect to the internet by connecting to the device's SSID name and entering the password.

① Lan Settings ② Wireless ③ Finish

2.4G Wireless

SSID: COMFAST-6162-2G

Password: (empty)

Country: China

Bandwidth: 40MHz

Channel: auto

5.8G Wireless

SSID: COMFAST-6162-5G

Password: (empty)

Country: China

Bandwidth: 40MHz

Channel: auto

Prev Next

6. Bridge Mode: The AP device can be configured with an internal network IP address. Next, select the wireless SSID signal name you wish to bridge (distinguishing between 5.8GHz and 2.4GHz), and enter the password for the bridged wireless network.

① Note: In bridge mode, when accessing the external network, other mobile devices connecting to the AP's wireless network will obtain IP addresses from the upper-level network segment;  
② By default, you do not need to set a specific internal network IP address for the device; however, if you need to manage the device, you must manually set the IP address of the computer's local network connection.

1) Set the internal network IP (this IP address can be used as the IP address for managing the device).

① Lan Settings    ② Bridge Settings    ③ Wireless     Finish

Lan Settings

IP Address: 192.168.10.1

Subnet Mask: 255.255.255.0

Next

2) Click Scan, search for and select the wireless SSID name you need to relay, and enter the password for the bridge wireless.

① Lan Settings    ② Bridge Settings    ③ Wireless     Finish

Bridge Settings

Scan Band: 2.4G

SSID: COMFAST-6576-2G

Password:

Scan

Prev    Next

3) Set the SSID name and password for the AP device itself at 2.4G/5.8G.

① Lan Settings    ② Bridge Settings    ③ Wireless    Finish

**2.4G Wireless**

SSID: COMFAST-6162-2G  
Password:

**5.8G Wireless**

SSID: COMFAST-6162-5G  
Password:

Prev    Next

7. Routing Mode: You can choose from three Internet access methods: "Broadband Internet Access", "Static Address", and "Dynamic Acquisition". (Refer to the standard router setup method.) Note: In Routing Mode, you must connect to Wi-Fi to access the management page if you need to manage the device.

① WAN Settings    ② Lan Settings    ③ Wireless    Finish

**WAN Settings**

PPPoE     Static     DHCP

IP Address:   
Subnet Mask:   
Gateway:   
DNS:

Next

8. Relay mode: The AP device can be set to internal network IR. Next, select the wireless SSID signal name you need to relay (distinguish between 5.8GHz and 2.4GHz), and enter the relay wireless password.

①Note: When accessing the external network in relay mode, other mobile devices accessing the AP's wireless network will obtain IP addresses assigned by this device.

### 1) Set the internal network IP.

Lan Settings

Repeater Settings

Wireless

Finish

Lan Settings

IP Address: 192.168.10.1

Subnet Mask: 255.255.255.0

Next

### 2) Search for the wireless SSID name you need to relay, and enter the password for the relay wireless.

Lan Settings

Repeater Settings

Wireless

Finish

Repeater Settings

Scan Band: 2.4G

SSID: COMFAST-6576-2G

Password:

Scan

Prev

Next

### 3) Set the SSID name and password for the AP device itself at 2.4G/5.8G.

① Lan Settings      ② Repeater Settings      ③ Wireless       Finish

### 2.4G Wireless

SSID

Password

### 5.8G Wireless

SSID

Password

Prev

Next

# **Quick Installation Guide**

## **Statement**

**Shenzhen Four Seas Global Link Network  
Technology CO.,Ltd.Company  
all rights reserved.**

Without ours official writ permission, no unit or individual shall be copied, reproduced, transcribed or translated in part or whole book. In any form or by any means(electronic,mechanical,printing,recording or other possible means)or for the propagation of goods any commercial, profitable purposes.

**COMFAST** is the registered trademark of Shenzhen Four Seas Global Link Network Technology Co.,Ltd.Company. All other trademarks or registered trademarks mentioned in this document, by respective owners.

Product specifications and information mentioned in this manual are for reference on subject to updates without notice. Unless there are other special agreed, this manual is used only as a user guide. All statements, information, etc. are not constitute any form of guarantee.

Manufacturer: Shenzhen Four Seas Global Link Network  
Technology Co.,Ltd.Company

Address: 9th Floor, Building H, Huanan Digital Valley, No. 1  
Huanan Road, Longhua District, Shenzhen, China

Hotline: +86 755 83790059

Website: [www.szcomfast.com](http://www.szcomfast.com)