COMFAST

Quick Installation Guide

Wireless Router
Version V1.0

1 Connection Diagram

1.1 If use dial-up internet, pls follow up below connection steps 1.2.3.4; If use broadband internet, pls follow up below connection steps 2.3.4 and connect WAN port of wireless router to internet directly.

Dial-up Internet



Broadband Internet



Wireless Connection

Scan wireless signal and the SSID is

COMFAST_MAC last 4 numbers_2G/
COMFAST_MAClast 4 numbers_5G

Power Socket

Wireless Router



4 Power Port

2 Connect WAN Port

3 Connect LAN Port

Wired Connection



Attention: This user manual is only for settings steps. If have more function requirements, pls visit our web: www.szcomfast.com

2 Setting Steps

2.1 After connecting the routing device, enter 192.168.0.1 in the address bar of your computer (mobile phone) browser to enter the device's setup wizard page. Click on "Experience Now".

2.2 Select the Internet access method, broadband dial-up mode needs to fill in the broadband account and password. Static IP mode requires IP address, subnet mask, gateway, and DNS server.

Attention: If login at the first time, it will go to "My guide" automatically. It is same if reset to factory settings.



2.3 Set the WiFi name and WiFi password. You can select "Dual-band in one". This means that 2.4G and 5.8G are combined and displayed under the same name.



2.4 Click" Done" to finish the settings. Then the interface will go to the home page; The device status will can be checked if log in again.



⚠ Warnings

1. Pls take off all connection if lightning weather in order to protect the device from damage.
2. Pls stay away from the heat source and keep ventilated.
3. Pls stay away from water when storage, transportation or working.
4. Pls use the power source which standard in the packing.
5. Pls put the device in a smooth surface.

3 FAQ

1. If I forget the login name and password of the device , what should I do(how to reset the router)?
A. If you forget the login name and password of the device, the only way you can do is do factory reset to the device, then the login name and password will be restored to their default values.
There is a RESET button between the power port and the LAN port on the device. When the device is powered on, press the RESET button for about 7 seconds to reset the device successfully.

2. What if i can't open the administrator page of device in browser?
A. Please make sure the ip address of your computer is in the same nerwork segment as the IP address of the device administrator page you typed in browser: for emample, if your device default login IP address is 192.168. 0.1, then the IP address of your computer should have been 192.168. 0.x (x is any integer between 2 and 254):
B. Please make sure your browser setting is "Never dial a connection" and disable proxy; Here is the steps of configuration (suppose you use IE): Click "Tools"-"Internet Options"-"Connections", choose"Never dial a connection";Click "Lan settings", remove the option of "Proxy server".
C. Try change another computer to log in: If all the 3 hints abobe can't help you, please do the Factory Reset Operation to the device and log in again.

3. Why my laptop can't search out the signal of Wi-Fi SSID?
A. If your laptop has network adapter built-in, please make sure the Wi-Fi function is enabled(we recommend you connect the laptop vendor or read the laptop user manual);
B. At device manager interface, check whether the driver of network adapter has been installed successfully;
C. Check whether the wifi service has been tureed on,right click the icon"my computer" on your desktop, choose manage. In "Computer Management" wizard, click"Services and Applications",then on the page of "Service", find the item "Wireless Zero Configuration" and check its Status value.
D. Please make sure you've enabled the wifi capability and enabled SSID broadcast.
E. Get closer to the router and try search agaiin, Avoid the factor of obstacles which reduce the intensity of signal;If the hints above can't help you, please chick out whether another wireless network adapter can connected to the router. If it still don't work, please do the factory reset operation to resrore the parameters back to their default values.

Quick Installation Guide

Statement
Shenzhen Four Seas Global Link Network Technology CO.,Ltd.Company all rights reserved.

Without ours official writ permission, no unit or individual shall be copied, reproduced, transcribed or translated in part or whole book. In any form or by any means(electronic,mechanical,printing,recording or other possible means)or for the propagation of goods any commercial, profitable purposes.

COMFAST is the registered trademark of Shenzhen Four Seas Global Link Network Technology Co.,Ltd.Company. All other trademarks or registered trademarks mentioned in this document, by respective owners.

Product specifications and information mentioned in this manual are for reference on subject to updates without notice. Unless there are other special agreed, this manual is used only as a user guide. All statements, information, etc. are not constitute any form of guarantee.

Manufacturer: Shenzhen Four Seas Global Link Network Technology Co.,Ltd.Company

Address: 9th Floor, Building H, Huanan Digital Valley, No. 1 Huanan Road, Longhua District, Shenzhen, China

Hotline: 0755 83790059/83790659
Website: www.szcomfast.com