

COMFAST


Quick Installation Guide




PCI-E High Speed Adapter
Version1.0

Product introduction

- Per se



④ Half height (8cm) bracket



① Fix the adapter on the chassis;

② Connect the mainboard to the PCI-E slot;

③ Connect the network cable;

④ 2U small chassis mounting bracket
(Replace the standard fixed bracket when installing the small case)


- **attachment**

1. 2U baffle
2. Instructions


Installation requirements

- The mainboard has a free PCI-E slot

Supports PCI-Ex1/x4/x8/x16 slots




Note: Do not install PCI interfaces




Product installation




Unscrew and open the side cover



Insert it into a PCI-E slot



Secure the bracket with screws



Access network cable

Maintenance Regulations

Dear Valued Clients,

Thank you for purchasing **COMFAST** products. To protect your rights and interests in after-sales service, please read the following maintenance regulations.

The following does not belong to free maintenance, our company can provide paid service, please note:

- Failure to require the installation manual, use, maintenance, storage led to product failure or damage;
- Beyond the limited warranty, the warranty period;
Unauthorized alteration, tearing up the product bar code;
- Without authorization to change the settings file or inherent disassemble;
- Unexpected factors or human actions lead to product damage, such as improper input voltage, temperature, watermechanical damage, break, rust or oxidation product of serious, etc;
- Other non-product itself, design, technology, manufacturing, quality and other quality problems caused by the failure damage.

Customer Data

Name	
Address	
Model	
MAC No.	
Machine unit sales	
Sale of machine address	
Date of sale machine	
TEL	
Post Code	
Invoice No.	

Certificate Of Qualification

Quality Inspector _____

Production Date _____

Executive Standard _____



YD/T 1965-2009

Copyright Information

Statement

**Shenzhen Four Seas Global Link Network
Technology CO.,Ltd.Company
all rights reserved.**

Without our official writ permission, no unit or individual shall be copied, reproduced, transcribed or translated in part or whole book. In any form or by any means(electronic,mechanical,printing,recording or other possible means)or for the propagation of goods any commercial, profitable purposes.

COMFAST is the registered trademark of Shenzhen Four Seas Global Link Network Technology Co.,Ltd.Company. All other trademarks or registered trademarks mentioned in this document, by respective owners.

Product specifications and information mentioned in this manual are for reference on subject to updates without notice. Unless there are other special agreed, this manual is used only as a user guide. All statements, information, etc. are not constitute any form of guarantee

Manufacturer: Shenzhen Four Seas Global Link Network
Technology Co.,Ltd.Company

Address: 9 / F, Block H, South China Digital Valley, No.1 South
China Road, Longhua District, Shenzhen, China

Hotline: +86 755 83790059

Website: en.comfast.com.cn